



AUGER ORDER PAGE

	<u>Diameter of Flight</u>	<u>Length of Flight</u>	<u>Notes</u>	<u>Part Number</u>
<u>Model 550</u>				
Left Hand	6"	-	Hollow Shaft	092-0168
Right Hand	6"	-	Hollow Shaft	092-0167
Left Hand	6"	32"	Sprocket & Shaft	092-0016
Left Hand	9"	32"	Sprocket & Shaft	092-0014
Right Hand	6"	32"	Sprocket & Shaft	092-0015
Right Hand	9"	32"	Sprocket & Shaft	092-0013
<u>Model 690 (except 690-F)</u>				
Left Hand	6"	32"	Sprocket & Shaft	092-0016
Left Hand	9"	32"	Sprocket & Shaft	092-0014
Right Hand	6"	32"	Sprocket & Shaft	092-0015
Right Hand	9"	32"	Sprocket & Shaft	092-0013
<u>Model 690-F (with Freedom Screed)</u>				
Left Hand	9"	32"	Sprocket & Shaft	092-0014
Right Hand	9"	32"	Sprocket & Shaft	092-0013
<u>Model 1100</u>				
Left Hand - UPPER	9"	34.5"	Sprocket & Shaft	092-0012
Left Hand - LOWER	6"	32"	Sprocket & Shaft	092-0016
Right Hand - UPPER	9"	34.5"	Sprocket & Shaft	092-0011
Right Hand - LOWER	6"	32"	Sprocket & Shaft	092-0015
<u>Model 1500 & 1720</u>				
Left Hand - UPPER	9"	34.5"	Sprocket & Shaft	092-0012
Left Hand - LOWER	9"	32"	Sprocket & Shaft	092-0014
Right Hand - UPPER	9"	34.5"	Sprocket & Shaft	092-0011
Right Hand - LOWER	9"	32"	Sprocket & Shaft	092-0013
<u>Model 1750</u>				
Left Hand - UPPER	9"	34.5"	Sprocket & Shaft	092-0012
Left Hand - LOWER	9"	34.5"	Sprocket & Shaft	092-0012
Right Hand - UPPER	9"	34.5"	Sprocket & Shaft	092-0011
Right Hand - LOWER	9"	34.5"	Sprocket & Shaft	092-0011
<u>Model 1750-C (with Symphony Screed)</u>				
Left Hand - UPPER	9"	34.5"	Sprocket & Shaft	092-0012
Left Hand - LOWER	9"	32"	Sprocket & Shaft	092-0014
Right Hand - UPPER	9"	34.5"	Sprocket & Shaft	092-0011
Right Hand - LOWER	9"	32"	Sprocket & Shaft	092-0013